

# **SR MARINER**

## **WS-1**

### **WIND SPEED METER**

#### **Installation Instructions**

Congratulations in choosing a high performance marine instrument and welcome to the growing family of SR Mariner product owners. Since our establishment in 1973, we have engineered our products to give you quality at a reasonable price.


To familiarize yourself with all the features and installation procedures please read the following instructions carefully.

If you still have any questions or comments please call your nearest dealer or call us at (716) 693-5977 or write:

SR Instruments  
600 Young Street  
Tonawanda, NY 14150  
Attn: Service Department

It is recommended that you temporarily hook up your SR MARINER equipment before installation so that you become familiar with its connections and system performance. DO NOT CUT ANY CABLES, but connect according to wiring diagram (fig.2). Spin the wind cups on the mast unit to test the system. If all functions perform satisfactorily, proceed with installation. If the system fails to perform, check all connections. If system still fails to perform check with your dealer for advice and or replacement if needed.

NOTE: This self powered instrument measures wind speed to 60 KNOTS or MILES per hour.



(Figure 1)


## INSTALLING THE DISPLAY

1. Cut a 4-1/16" (max 4-1/8") diameter hole in the bulkhead or instrument panel where the display unit is to be mounted (fig.1).
2. Be sure to remove all burrs and clean the face of the bulkhead or panel with detergent to remove all traces of dirt, oils, fingerprints, etc...
3. Each display unit is furnished with an adhesive backed sealing ring to hold the unit fast in place and creates a watertight seal. Please note that it is not recommended that the paper backing be removed until the system is tested and finally calibrated. When ready for final mounting simply remove the paper backing, position unit correctly and firmly press into place.
4. Install the RETAINING RING as shown and tighten with a blade type screwdriver.

## INSTALLING THE MAST UNIT

1. Mount the mast unit (MWS) to the top of the mast with four screws.
2. Take the connector of the 65 foot cable and connect to the mast unit. run the free end of the cable down or through the mast, exiting above or below the deck as conditions permit. Cut the cable to length.
3. Splice the 2 foot cable to the free end of the 65 foot cable. It is preferred to solder and tape these connections, but if not convenient, use the crimp connectors provided.
4. Connect the 20 foot cable and run the free end to the display. Cut to length and attach terminals to the wires.

## BACK OF DISPLAY



(Figure 2)

## WIRING AND CALIBRATION

1. Connect the cable wires to the display as shown in figure 2.
2. If you choose to connect night lighting, simply connect your 12 volt D.C. wire as indicated above and install a SPST switch on the positive (+) line to complete the circuit and activate the lights.
3. Your unit is factory calibrated to read KNOTS and should not require any adjustments, however, if a condition exists to which you find it necessary to recalibrate, simply remove the plastic plug from the hole marked CAL.
4. Evaluate proper reading and adjust the calibration potentiometer accordingly. The same adjustment may be used to read either KNOTS or STATUTE MILES. NOTE: PLEASE DO NOT APPLY EXCESSIVE FORCE TO THE CALIBRATION POT.

## POWER CONSUMPTION

LIGHTS	AMPS
OFF	.0A
ON	.050A

## TROUBLESHOOTING

**WIND SPEED NOT WORKING-** The wind speed generator can be tested two ways. First, disconnect the wires from the back of the display and measure those same wires:

(1) IF THE CUPS ARE NOT SPINNING- measure with an ohm meter across the GREEN and WHITE wires. You should get a resistance reading of 600 - 800 ohms.

(2) IF CUPS ARE SPINNING- measure with a voltmeter on the AC scale using the following scale:

05 KNOTS = .30 VOLTS AC	20 KNOTS = 1.20 VOLTS AC
10 KNOTS = .60 VOLTS AC	25 KNOTS = 1.50 VOLTS AC
15 KNOTS = .90 VOLTS AC	30 KNOTS = 1.80 VOLTS AC

**WIND SPEED IS READING LOW-** There are several possibilities for a low reading:

- (1) The generator may need lubrication. This is more apparent if you hear a vibration coming down the mast. Please follow the lubrication procedure further in the manual. (*Please note that if you find your anemometer cups breaking frequently, then please check the generator.*)
- (2) The display may need to be recalibrated. If you know what the wind speed is, then adjust the calibration potentiometer to that reading. If the wind speed is not known, then please use the above values to guide you for the proper wind speed reading.
- (3) The meter movement may need replacing. As the resistance of the meter movement goes up, your readings will decrease. If this is possible, then please ship to the unit in for repair to the address on the front of the manual.

## ACCESSORIES

FRWV	WIND VANE
EV5K6637S	5K POT FOR MAST UNIT
FRAC	ANEMOMETER CUPS AND HARDWARE
FRAG	ANEMOMETER GENERATOR
FRICW-1	INSTRUMENT COVER
FRCLP RNG	CLAMP RING
FRMC-1	METER CASE FOR (YOUR MODEL NUMBER)
FRSEAL RING	GASKET FOR INSTRUMENT GAUGE

## **PROCEDURE FOR LUBRICATING ANEMOMETER GENERATOR**

**IMPORTANT: IT IS RECOMMENDED THAT THIS PROCEDURE BE DONE ON A FLAT CLEAN SURFACE. ALSO, BEFORE STARTING THE PROCEDURE, TAPE THE WEIGHTED END OF THE WINDVANE TO THE MAST PIPE TO ENSURE CORRECT VANE ORIENTATION AND CALIBRATION.**

1. Remove cap plug, hex nut, and lock washer at the center of the three cup assembly.
2. Remove cup assembly from the threaded shaft by lightly prying apart.
3. Remove the 2 OUTER screws in the plastic cap located at the 3 and 9 o'clock positions.
4. Generator is now free to separate from housing.
5. Lubricate shaft above and below the magnet with a TEFLON base lubricant.
6. Reset the generator into housing, reversing step 4.
7. Replace the 2 outer screws in the cap that were removed in step 3.
8. Lubricate base of the threaded shaft where it meets the plastic cap.
9. Rotate shaft by hand to make sure it spins freely.
10. Reset cup assembly onto shaft while making sure they are seated properly.
11. Replace lock washer, hex nut, and cap from step 1.
12. Check operation of mast unit.

**MASTUNIT ASSEMBLY**

EXPLODED VIEW

